

All weather Breather and Nose Net size guide



1. Measure your horse's head

Use a soft tape measure (or a piece of string) to measure in centimeters from the protruding cheek bone to the bottom of the nostril as shown by the yellow line and then measure all the way round the nose placing the tape in the chin groove and just behind the nostrils as shown by the green line.

The size of the horse does not necessarily determine the size of All Weather Breather (AW) needed as head sizes are very variable irrespective of body size. So it's important to take these measurements in order to get an AW that will fit.

It's not so critical to measure your horse's head for a Nose Net and a guesstimate using the size guide on the order form will probably be fine if you don't want to actually measure.

2. Check the measures against the chart below to determine the size of the AW and or Nose Net

protruding cheek bone to bottom of nostril (yellow line)

circumference round nose, along chin groove and behind nostrils (green)

size of AW or Nose Net required

20.5 to 22 cm	38 to 42 cm	small
22 to 26 cm	42 to 47 cm	medium
26 to 31.5 cm	47 to 53.5 cm	large
31.5 to 34 cm	53.5 to 60 cm	extra large